


Range Hood Assembly



NO.	PART NAME
1	US cord
2	switch wire
3	damper
3a	round damper optional
4	body
5	top & rear
6	speed rocky switch
7	LED rocky switch
8	clamp
9	PCB
10	electric supply box
11	panel piece
12	motor
13	bracket
14	impeller
15	housing
16	LED light
17	aluminum filter